Stainless steel Citrus Juicer

SY-EX17

INTRODUCTION

Thank you for having purchased the citrus juicer SY-EX17. To fully benefit from the juicer please read this user manual carefully. We hope that you enjoy your new citrus juicer SY-EX17

GENERAL DESCRIPTION



Parts name:

1 Dust cover
2 Juicer cone
3 Pulp sieve
4 Juice container
5 Drive shaft
6 Base unit
7 Power cord with plug

IMPORTANT

Read this user manual carefully before you use the appliance and save it for future reference.

Danger

- Do not immerse the motor unit in water nor rinse it under the tap.

Warning

- Check if the voltage indicated on the bottom of the appliance corresponds to the local mains voltage before you connect the appliance.
- If the mains cord is damaged, you must have it replaced by Sytech Service Centre in order to avoid a hazard
- Do not use the appliance if the plug, the mains cord or any other parts are damaged.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Always keep the SY-EX17 unplugged when not in use.

Caution

- Always place the appliance on a flat, stable surface
- Do not use the citrus press longer than 1 minute without interruption
- This appliance is only meant for soft fruits, such as oranges or lemons.
- This appliance is intended for household use only.
- Never use any accessories or parts from other manufacturers or that Sytech doesn't recommend. If you do use such parts that are not recommended by Sytech, the guarantee becomes void/invalid.

Preparing for use

1. Clean all detachable parts before you use the appliance for the first time.
2. Make sure the appliance is assembled properly before you put the plug in the wall socket.
3. Remove the dust cover from the appliance.
4. Put the plug in the wall socket.

USING THE SY-EX17

1. Open the storage compartment on the underside of the appliance and take out the juicer cone.
2. Attach the juice container to the drive shaft of the base unit.
3. Place the pulp sieve in the container
4. Fit the juicer cone on to the drive shaft
5. Push the spout upwards to ensure that the extracted juice remains in the container.
6. However, the juice may also be collected straight into a suitable container placed

under the spout: in this case, the spout must face downwards.
7. Insert the plug into a suitable wall socket.
8. Cut the citrus fruit in half and push one of the halves lightly down on to the cone with the cut section facing downwards.
9. The drive shaft will start rotating automatically once pressure is applied to the cone. The appliance switches off automatically when the pressure on the cone is lifted.
10. When processing larger quantities of fruit, the pulp sieve must be emptied from time to time.
11. To collect the juice, place a suitable container under the spout .Push the spout downwards. The extracted juice passes now straight into the container. Once the desired amount of juice has been collected, push the spout upwards again to fill the juice container.
12. Remove the main plug from the wall once you have finished using the juicer.

TIP: Sytech recommends cleaning the appliance immediately after use as dried fruit pulp is more difficult to remove. (See under "Cleaning")

Cleaning

1. Always make sure that the appliance is unplugged before cleaning.
2. Remove all detachable parts from the motor unit.
3. Separate the sieve and the cone.
4. Clean all the detachable parts with hot water and some washing-up liquid or otherwise, they can even be washed in the dishwasher.
5. Do not use abrasives, harsh cleaning solutions or a hard brush for cleaning.
6. Clean the motor unit with a moist cloth.

NOTE: Never immerse the motor unit in water nor rinse it under the tap.

Storage

1. Store the appliance in a safe and dry place.

SPECIFICATIONS

Operating voltage: 220V~240V / 50Hz
Capacity: 1.2 L
Power: 85W
KB: 5 minutes
Working mode: 15 seconds max. (Wait 15 seconds for second use). Max. 10 cycles

ENVIRONMENTAL DISPOSAL

You can help protect the environment!
Please remember to respect the local regulations: hand
In the non-working electrical equipments to an
Appropriate waste disposal centre

DECLARATION OF CONFORMITY
Manufacturer Name: Satyatrade S. L.
Address: Pol. Ind. La Raya. C/ Guadalquivir, 2.
Camarma de Esteruelas, 28816 Madrid
Tel: 902 430 967
Fax: 91 8864285
NIF: B83254763
Manufacturing country: China
Sytech® SY-EX17 complies with the following directives:

CE standard: EMC Directive 2004/108/EC

EN 55014-1: 2006/+A1:2009
EN 55014-2: 1997/+A1:2001/+A2:2008
EN 61000-3-2: 2006/+A1:2009/+A2:2009
EN 61000-3-3:2008

Low Voltage:
EN 60335-2-14:2006+A1:2008
EN 60335-1:2002+A11, A1:04+A12, A2:06+A13:08+A14:10
EN 62233:2008

ROHS standard: 2002/95/EC Restriction of Hazardous Substance

Signed: Ajeet Nebhwani Utamchandani
Sole Administrator